

# Algo IP Endpoints and Microsoft Teams SIP Gateway Interoperability

Guide – Testing & Configuration





For additional support, call (604) 454-3792 or email support@algosolutions.com

AL061-GU-CP00TEAM-20230420 Firmware Version 5.3.4 support@algosolutions.com November 03, 2022 Algo Communication Products Ltd. 4500 Beedie Street, Burnaby V5J 5L2, BC, Canada 1-604-454-3790 www.algosolutions.com



## **Information Notices**



## Note

Note indicates useful updates, information, and instructions that should be followed

# Disclaimer

The information contained in this document is believed to be accurate in all respects but is not warranted by Algo. The information is subject to change without notice and should not be construed in any way as a commitment by Algo or any of its affiliates or subsidiaries. Algo and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes. Algo assumes no liability for damages or claims resulting from any use of this manual or such products, software, firmware, and/or hardware.

No part of this document can be reproduced or transmitted in any form or by any means – electronic or mechanical – for any purpose without written permission from Algo.

For additional information or technical assistance in North America, please contact Algo's support team:

Algo Technical Support 1-604-454-3792 support@algosolutions.com

©2023 Algo® is a registered trademark of Algo Communication Products Ltd.

All Rights Reserved. All other trademarks are the property of their respective owners. All specs are subject to change without notice.



# Table of Contents

1	Ģ	General	1
	1.1	Introd	Juction1
	1.2	Consi	derations2
2	C	Configura	ition Steps3
	2.1	Requi	irements
	2.2	Instru	ictions3
2.2.1 Register Algo IP Endpoint in Microsoft Teams		2.2.1	Register Algo IP Endpoint in Microsoft Teams
	2	2.2.2	Enable Teams Support in Algo IP Endpoint5
	2	2.2.3	Pairing an Algo IP Endpoint with Microsoft Teams6
3	F	Registerir	ng Additional or Different Types of Extensions8
4	Т	roublesh	nooting9
	4.1	My de	evice does not provision with Microsoft's server9
	4.2	My de	evice does not reboot after entering the pairing code9

# Figures

Figure 1: Basics tab	4
Figure 2: Product Licenses tab	4
Figure 3: User successfully created	
Figure 4: Enabling Teams Support	
Figure 5: Successful SIP Registration	
Figure 6: Login	
Figure 7: Enter pair code	7
Figure 8: Successful Microsoft Teams Registration	



# 1 GENERAL

## 1.1 Introduction

Algo IP Endpoints are certified for native compatibility with the Microsoft Teams SIP Gateway, accommodating dozens of different applications, from IP paging to emergency alerting, and hands-free visitor communication.

Registering Algo IP Endpoints to the Teams SIP Gateway is a quick and straight-forward process. In the following sections, this guide will go over the required steps to configure and register Algo IP Endpoints to Microsoft Teams, as well as discuss the different applications and considerations.

The following endpoints are compatible with the Microsoft Teams SIP Gateway:

#### **IP** Speakers

- 8180G2 IP Audio Alerter
- 8186 IP Horn Speaker
- 8188 IP Ceiling Speaker
- 8189 IP Surface Mount Speaker
- 8190 IP Speaker Clock
- 8190S IP Speaker Clock & Visual Alerter
- 8196 IP PoE+ Horn Speaker

#### IP Intercoms

- 8028G2 IP Doorphone
- 8201 IP PoE Intercom
- 8063 IP Door Controller

#### **IP Visual Alerters**

- 8128G2 IP Visual Alerter
- 8138 IP Color Visual Alerter

#### **IP Paging Adapters**

- 8301 IP Paging Adapter & Scheduler
- 8373 IP Zone Paging Adapter

#### IP Display Speakers

- 8410 IP Display Speaker
- 8420 IP Dual-Sided Display Speaker



# 1.2 Considerations

In most cases, only one Algo IP Endpoint will require a SIP registration to Microsoft Teams. Leveraging multicast, Algo IP Endpoints can scale the solution to any number and combination of endpoints, without requiring each endpoint to be registered to Microsoft Teams. Multicast is a cost-effective solution accommodating up to 50 zones and allowing for ease of scalability.

To register an Algo IP Endpoint into Microsoft Teams, it must be associated with a Microsoft account. This is typically done with a Shared Device License, although it may instead be associated with a full user license.

Applications requiring multiple extensions to be registered to a single endpoint may require additional Algo devices. However, only a single SIP extension may be initially registered on any given endpoint through Microsoft SIP Gateway.



#### Note

Only one SIP extension may be registered to any given Algo endpoint at a time with the Microsoft Teams SIP Gateway. For more information, please contact Algo support.

For applications requiring two-way communication (e.g., an IP intercom deployed for visitor communication and secure door entry), each endpoint will require its own Microsoft Teams Shared Device License.

For general information related to Microsoft Teams compatibility or different use cases, please contact Algo support.



# 2 CONFIGURATION STEPS

## 2.1 Requirements

The following requirements are necessary to register an Algo Device to the Microsoft Teams SIP Gateway.

- Access to Algo's web interface
- Firmware 5.3.4 or higher
- Microsoft Teams support must be enabled in the Algo firmware
- Microsoft SIP Gateway must be enabled trough the Teams Admin Center
- A Microsoft Teams License available in the Teams Admin Center
- Microsoft Teams production environment must support Algo devices
- Device certificate installed
  - See the System  $\rightarrow$  About tab on Algo's web interface.



#### Note

Any Algo endpoint shipping in 2019 or later will have the certificate installed from the factory. If the certificate is not currently installed, please contact Algo's support team.

## 2.2 Instructions

## 2.2.1 Register Algo IP Endpoint in Microsoft Teams

- 1. To register an Algo IP Endpoint to Microsoft Teams, ensure the Microsoft Teams SIP Gateway is enabled. Follow the Instructions provided <u>here</u>.
- 2. Add a user in the Microsoft 365 Admin Center. See the Microsoft Teams support site for more information.
  - a. Go to the Microsoft 365 Admin Center
  - b. Navigate to Users  $\rightarrow$  Active Users.
  - c. Press Add a user and enter the information required in the *Basics* tab as per the example below.



# Add a user

Bas	ics	Set up the basics	
O Pro-	duct licenses	To get started, fill out some basic information ab	out who you're adding as a user.
O Opt	ional settings		
		First name	Last name
O Fini	sh		
		Display name *	
		Algo 8301 Shared Device Paging	
		Username *	Domains
		algo_shared_paging @	algosolutions.com V

3. On the next screen (Product licenses tab), assign licenses as required. Generally, only a Teams Shared Device License is required. For more details, refer to the Considerations section above. Proceed through the next steps to finish adding the account.



Basics	Assign product licenses
Product licenses	Assign the licenses you'd like this user to have.
Optional settings	Select location *
	Licenses (1)*
	<ul> <li>Assign user a product license</li> <li>Microsoft 365 Audio Conferencing You don't have any licenses available. To purchase additional licenses, please contact your partner(s).</li> </ul>
	Microsoft 365 Business Standard You don't have any licenses available. To purchase additional licenses, please contact your partner(s).
	Microsoft Power Automate Free 9972 of 10000 licenses available
	Microsoft Teams Phone Standard 1 of 36 licenses available
	Microsoft Teams Shared Devices 1 of 3 licenses available
	Figure 2: Product Licenses tab

4. Verify that the user has been created successfully.



## Add a user

0	Basics Product licenses	Algo 8301 Shared Device Paging added to active users
   	Optional settings	Algo 8301 Shared Device Paging will now appear in your list of active users.
•	Finish	User details Display name: Algo 8301 Shared Device Paging Username: algo_shared_paging@algosolutions.com Password: Password will be sent to:
		Licenses bought None
		Licenses assigned Microsoft Teams Shared Devices
		Figure 3: User successfully created

5. Ensure that a DID (phone number) is associated with the recently created account before proceeding tot eh next step.



#### Note

The next steps cannot be completed without a valid DID associated with the account.

6. The configuration on the Microsoft 365 Admin Center is finished.

#### 2.2.2 Enable Teams Support in Algo IP Endpoint

- 1. Navigate to web UI of the Algo IP Endpoints you wish to register to Teams
- 2. Log in using the Algo credentials.
- 3. Go to Advanced Settings  $\rightarrow$  Admin.
- 4. Towards the bottom of the page, enable Microsoft Teams Support.
- 5. Select the SIP Gateway Region based on the region where the Algo endpoint is deployed.
- 6. Save and reboot when prompted.



#### Note

Enabling this setting will provision the device via Microsoft's servers. The device reboot will take <u>up to 5 minutes</u> to complete.

Microsoft	
Microsoft Teams Support	Enabled Obisabled Inabling this setting will provision the device via Microsoft's servers. The device reboot will take up to 5 minutes to complete. This feature requires a compatible release from Microsoft.
SIP Gateway Region	Americas (North & South America) Y
ADMP Cloud Monitoring	
Enable ADMP Cloud Monitoring	<ul> <li>Enabled Obisabled</li> <li>This feature requries a valid Account ID. Please contact support@algosolutions.com for assistance.</li> </ul>
1	✓ Save

#### Figure 4: Enabling Teams Support

Once the Algo web interface reloads (after approximately 5 minutes), a section for Microsoft Teams will become enabled, and the SIP registration status will show as successful.

ALGO	8301 IP Paging Adapter & Scheduler	Firmware: 5.3
Welcome to the Algo	8301 IP Paging Adapter & Scheduler	
5.7 55		
- ·		
Step 2: Check network sett	tings (Optional)	
Step 3: Secure your IP Pag	ing Adapter & Scheduler (Optional)	
A		
Step 4: Register your IP Pa	e to the Algo 8301 IP Paging Adapter & Scheduler: ory our IP Paging Adapter & Scheduler: ht default password and use the Basic Settings pages to set up the basic information. heck network settings (Optional) etwork page under the Advanced Settings tab to change network settings. The default setting for the device is to obtain its IP om a DHCP server. Contact your Network System administrator if you plan to assign a static IP address, Mask, and Gateway to the ecure your IP Paging Adapter & Scheduler (Optional) dmin page under the Advanced Settings tab to change the administrator password. ng the password is extremely important if the device is directly connected to a public network. egister your IP Paging Adapter & Scheduler (Optional) gister your product using the link below: w.algosolutions.com/register on ensures your access to the latest upgrades to this product and important service notices. of Teams Code: 4620414B9 ign in with the Microsoft account that you would like this device to pair to and enter the pairing code. Note: The device will ically reboot if the sign in is successful, please refresh the page after 2 minutes. enter Pairing Code Sign In Name pagingadapter-09497c	
Please register your product	: using the link below:	
http://www.algosolutions.co	<u>om/register</u>	
Registration ensures your ac	ccess to the latest upgrades to this product and important service notices.	
Microsoft Teams		
automatically reboot if the	crosoft account that you would like this device to pair to and enter the pairing code. <b>Note:</b> The d sign in is successful, please refresh the page after 2 minutes.	evice will
Generate New Pairing Code	[Sign In]	
Login		
Password (default: algo)	🔛 🕨 Login	
Status		
Device Name	pagingadapter-09497c	
SIP Registration	Page Successful (Extension 0022EE09497C	qFMsbEGJ)

Figure 5: Successful SIP Registration

# 2.2.3 Pairing an Algo IP Endpoint with Microsoft Teams

A pairing code will be required to associate the Microsoft Teams account with this endpoint.



- 1. In the *Status* tab of the Algo web interface, press **Sign In** under the Microsoft Teams section.
- 2. A new browser tab will be opened, redirecting to the Microsoft Login Portal. Enter the email and password to log in.





3. After signing in, enter the pairing code provided. The device will automatically reboot if the sign in is successful. If the pairing is not accepted, regenerate the code, and enter again.



#### Note

The pairing code expires after a few minutes. If that happens, a new code may be regenerated by pressing the **Generate New Pairing Code** button.



Figure 7: Enter pair code



4. Wait approximately 2 minutes and then refresh the Algo web interface page. The Microsoft Teams section should now display "Registered". It's also possible to verify a successful registration in the SIP registration portion on the *Status* tab.

ALGO	8301 IP Paging Adapter & Scheduler Firmwar
Velcome to the Algo 830	Paging Adapter & Scheduler
Setting up your IP Paging Adapte	55
Step 1: Configure your IP Pagin	
	use the Basic Settings pages to set up the basic information.
Step 2: Check network settings	
Jse the Network page under the	nced Settings tab to change network settings. The default setting for the device is to obtain its IP your Network System administrator if you plan to assign a static IP address, Mask, and Gateway to
Step 3: Secure your IP Paging	er & Scheduler (Optional)
· -	ed Settings tab to change the administrator password. y important if the device is directly connected to a public network.
Step 4: Register your IP Paging	iter & Scheduler (Optional)
Please register your product usir	link below:
http://www.algosolutions.com/re	1
legistration ensures your acces	e latest upgrades to this product and important service notices.
Microsoft Teams	
Registered.	
The device will automatically re	after signing out, please refresh the page after 2 minutes.
Sign Out	
_	
Login	
Password (default: <b>algo</b> )	🔤 🕨 Login
Status	
Device Name	pagingadapter-09497c
SIP Registration	Page Successful (Extension +16044543767)

Figure 8: Successful Microsoft Teams Registration

5. To ensure the successful pairing of the device to Microsoft Teams, call the DID (phone number) associated with the account. In the default settings, the Algo IP endpoint will auto-answer and open a one-way audio path.

At this point, Microsoft Teams should be completely configured. If there are multiple Algo IP endpoints deployed, they may be configured in multicast transmitter / receiver mode. Please refer to the Multicast Guide for more information.

# **3** REGISTERING ADDITIONAL OR DIFFERENT TYPES OF EXTENSIONS

The steps outlined in the previous section imply that the endpoints will be set up for public announcing. However, Algo devices may support different types of extensions, accommodating different applications, such as loud ringing or emergency alerting.

For information on registering different types of extensions to Microsoft Teams, please contact Algo support.



## 4 TROUBLESHOOTING

In the following sections, some of the more frequent issues and how to resolve them are outlined. Please go through the information carefully and ensure everything is configured according to this guide. If further assistance is required, please contact Algo <u>support</u>.

## 4.1 My device does not provision with Microsoft's server.

For successful provisioning, please ensure the Algo device has access to the public internet. If there are VLANs or subnets, make sure there is external network access to the particular server the Algo device is deployed to.

## 4.2 My device does not reboot after entering the pairing code.

A failure for an Algo device to reboot may be caused by lack of a DID (phone number) associated with the Teams account. Please ensure a DID is associated and try again.